

PHASING

PHASE I

STEP 1
USING RSD 1101.01, INSTALL ALL WORK ZONE ADVANCE WARNING SIGNS ON -L-.

STEP 2
USING RSD 1101.02, SHEET 4 OF 14, INSTALL PCB TO LOCATION SHOWN ON TMP-5 AND 6.

STEP 3
BEHIND PCB AND USING RSD 1101.02, SHEET 4 OF 14 AS NECESSARY, INSTALL TS LOC 1 AND 2 AND CONSTRUCT -EBL_DET- FROM 297+00± TO 332+10± UP TO, BUT NOT INCLUDING THE FINAL LAYER OF SURFACE COURSE. SEE TMP-4 THRU TMP-6.

NOTE - CONTRACTOR SHALL COORDINATE ALL OVERHEAD WORK FOR QUARRY RD (WHICH REQUIRES THE NIGHT TIME CLOSURE OF QUARRY RD) WITH THE ENGINEER.

STEP 4
USING RSD 1101.02, SHEET 4 OF 14, CONSTRUCT THE FOLLOWING IN ORDER:
A - WEDGE AND RESURFACE THE EB LANES AS SHOWN ON TMP-4 AND 6.
B - INSTALL TEMPORARY PAVEMENT MARKINGS AND MARKERS. SEE TMP-7 THRU TMP-9.
C - INSTALL PCB NECESSARY FOR EBL SHIFT. SEE TMP-8 AND TMP-9
D - INSTALL SPEED LIMIT REDUCTION DEVICES SHOWN ON TMP-2B
E - SHIFT EB TRAFFIC TO NEWLY CONSTRUCTED DETOUR LANES. SEE TMP-7 THRU TMP-9.

PHASE II

STEP 1
USING RSD 1101.02, SHEET 4 OF 14, INSTALL REMAINING PCB AS SHOWN ON TMP-7 THRU TMP-9 ON -WBL_DET- AND REMOVE EXISTING GUARD RAIL AS DIRECTED BY THE ENGINEER.

USING RSD 1101.02, SHEET 4 OF 14, INSTALL SINGLE LAYER OF SURFACE COURSE AS FOLLOWS:
-L- 303+33± TO 305+65± SEE TMP-4
-L- 323+18± TO 325+47± SEE TMP-6

STEP 2
BEHIND PCB AND USING RSD 1101.02, SHEET 4 OF 14 AS NECESSARY, INSTALL PERMANENT BARRIER AS SHOWN ON TMP-8.

USING RSD 1101.02, SHEET 4 OF 14 AS NECESSARY, INSTALL TS LOC 3 AND 4 AND CONSTRUCT -WBL_DET- FROM 297+00± TO 333+04± UP TO, BUT NOT INCLUDING, FINAL LAYER OF SURFACE COURSE. SEE TMP-7 THRU TMP-9.

NOTE - CONTRACTOR SHALL COORDINATE ALL OVERHEAD WORK FOR QUARRY RD (WHICH REQUIRES THE NIGHT TIME CLOSURE OF QUARRY RD) WITH THE ENGINEER.

STEP 3
USING RSD 1101.02, SHEET 4 OF 14, CONSTRUCT THE FOLLOWING IN ORDER:
A - WEDGE AND RESURFACE WB LANES AS SHOWN ON TMP-7 AND TMP-9.
B - INSTALL TEMPORARY PAVEMENT MARKINGS AND MARKERS. SEE TMP- 10 THRU TMP-12.
C - INSTALL PCB FOR WB SHIFT. SEE TMP-10 THRU TMP-12.
D - INSTALL SPEED LIMIT REDUCTION DEVICES SHOWN ON TMP-2B
E - SHIFT WB TRAFFIC TO NEWLY CONSTRUCTED DETOUR LANES. SEE TMP-10 THRU TMP-12.

PHASE III

STEP 1
USING RSD 1101.02, SHEET 4 OF 14, AS NECESSARY, CONSTRUCT -L- FROM 297+00± TO 332+10± UP TO, BUT NOT INCLUDING, THE FINAL LAYER OF SURFACE COURSE. SEE TMP-10 THRU TMP-12.

NOTE - CONTRACTOR SHALL COORDINATE ALL OVERHEAD WORK FOR QUARRY RD (WHICH REQUIRES THE NIGHT TIME CLOSURE OF QUARRY RD) WITH THE ENGINEER.

STEP 2
USING RSD 1101.02, SHEET 4 OF 14, INSTALL TEMPORARY PAVEMENT MARKINGS AND MARKERS TO WB LANES. SEE TMP-13 THRU TMP-15 AND PM PLANS.

STEP 3
USING RSD 1101.02, SHEET 4 OF 14, SHIFT WB TRAFFIC TO FINAL PATTERN. SEE TMP-13 THRU TMP-15.

NOTE - PLACE/INSTALL TMA OR TCC TO PROTECT EXPOSED END OF PERMANENT BARRIER AS NEEDED AND AS DIRECTED BY THE ENGINEER. SEE TMP-14.

PHASE IV

STEP 1
USING RSD 1101.02, SHEET 4 OF 14, CONDUCT THE FOLLOWING OPERATIONS IN ORDER:
A - CONSTRUCT ALL REMAINING PERMANENT BARRIER BEGINNING AT -L- STA 299+10± AND WORKING NORTHWARD. SEE TMP-13 THRU TMP-15.

B - INSTALL TEMPORARY PAVEMENT MARKINGS AND MARKERS TO EB LANES IN FINAL PATTERN. SEE PM PLANS.

STEP 2
REMOVE ALL SPEED LIMIT REDUCTION DEVICES AND USING RSD 1101.02, SHEET 4 OF 14, SHIFT EB TRAFFIC TO FINAL PATTERN. SEE ROADWAY PLANS.




PHASE V

STEP 1
USING RSD 1101.02, SHEET 4 OF 14, CONDUCT THE FOLLOWING OPERATIONS IN ORDER:
A - INSTALL PCB AS SHOWN ON TMP-16.
B - BEHIND BARRIER, CONSTRUCT BRIDGE RAIL AS SHOWN ON TMP-16.
C - REMOVE PCB.

STEP 2
USING RSD 1101.02, SHEET 4 OF 14, CONDUCT THE FOLLOWING OPERATIONS IN ORDER:
A - INSTALL FINAL LAYER OF SURFACE COURSE TO ALL LANES.
B - INSTALL FINAL PAVEMENT MARKINGS AND MARKERS TO ALL LANES. SEE PM PLANS.

STEP 3
REMOVE ALL REMAINING WORK ZONE DEVICES.

8/22/2022
U:\Traffic\Transportation Management Plan\TCP\PLAN SHEETS\B-4442-TMP-03-PHASING.dgn
dorichardson

 <p>Stantec Consulting Services Inc. 801 Jones Franklin Road Suite 300 Raleigh, NC 27606 Tel. 919.851.6866 Fax. 919.851.7024 www.stantec.com License No. F-0672</p>	<p>8/22/2022</p>  <p>DocuSigned by: J. W. Woodard BB02F49E93C4EC</p> <p>DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED</p>	 <p>DIVISION OF HIGHWAYS DEPARTMENT OF TRANSPORTATION WORK ZONE TRAFFIC CONTROL</p>	<h1 style="margin: 0;">PHASING</h1>
--	---	--	-------------------------------------