
| WATTLE | <b>BARRIER</b> | DETAIL |
|--------|----------------|--------|
|        |                |        |

| PROJECT REFERENCE NO.      |  | SHEET NO.              |  |  |
|----------------------------|--|------------------------|--|--|
| BR-0029                    |  | EC-2A                  |  |  |
| R/W SHEET NO.              |  |                        |  |  |
| ROADWAY DESIGN<br>ENGINEER |  | HYDRAULICS<br>ENGINEER |  |  |
|                            |  |                        |  |  |
|                            |  |                        |  |  |
|                            |  |                        |  |  |



## 2' WOODEN STAKE 4 FT. 2" 18" WATTLE 15"-16" 2 FT. SEE INSET A

## FRONT VIEW

## NOTES:

USE MINIMUM 18 IN. NOMINAL DIAMETER EXCELSIOR WATTLE AND LENGTH OF 10 FT.

EXCAVATE A 2 TO 3 INCH TRENCH FOR WATTLE TO BE PLACED.

DO NOT PLACE WATTLES ON TOE OF SLOPE.


USE 2 FT. WOODEN STAKES WITH A 2 IN. BY 2 IN. NOMINAL CROSS SECTION.


INSTALL A MINIMUM OF 2 UPSLOPE STAKES AND 4 DOWNSLOPE STAKES AT AN ANGLE TO WEDGE WATTLE TO GROUND.

PROVIDE STAPLES MADE OF 0.125 IN. DIAMETER STEEL WIRE FORMED INTO A U SHAPE NOT LESS THAN 12" IN LENGTH.

INSTALL STAPLES APPROXIMATELY EVERY 1 LINEAR FOOT ON BOTH SIDES OF WATTLE AND AT EACH END TO SECURE IT TO THE SOIL.

FOR BREAKS ALONG LARGE SLOPES, USE MAXIMUM SPACING OF 25 FT.





TOP VIEW