

PHASING




- STEP 1: USING ROADWAY STANDARD DRAWING (RSD) 1101.01 SHEET 3 OF 3 INSTALL ADVANCE WORK ZONE WARNING SIGNS ON NC 42 AND -Y- LINES.
- STEP 2: USING RSD 1101.02 SHEET 1 OF 19 AND 1101.04 SHEET 1 OF 2 AS NECESSARY, BEGIN CONSTRUCTION ON THE RIGHT SIDE OF -L- FROM -L- STA 10+00± TO -L- STA 30+35± AND ON THE LEFT SIDE OF -L- FROM -L- STA 10+00± TO -L- STA 28+00± UP TO BUT NOT INCLUDING THE FINAL LAYER OF SURFACE COURSE AS SHOWN ON TMP-2 AND TMP-3.
- STEP 3: USING RSD 1101.02 SHEET 1 OF 19, AND 1101.04 SHEET 1 OF 2 AS NECESSARY COMPLETE CONSTRUCTION ON THE RIGHT SIDE OF -L- FROM -L- STA 26+67± TO -L- STA 30+35± UP TO BUT NOT INCLUDING THE FINAL LAYER OF SURFACE COURSE.

NOTE: CONTACT THE CENTURY CENTER RESIDENT ENGINEERS OFFICE AT (919)707-7370 TO COORDINATE THE PROPOSED TRAFFIC SHIFT WITH PROJECT TIP NO HL-00080

- STEP 4: USING RSD 1101.02 SHEET 1 OF 19 AND 1101.04 SHEET 1 OF 2 AS NECESSARY, PLACE TEMPORARY MARKINGS, TRAFFIC CONTROL DEVICES, AND SHIFT TRAFFIC AS SHOWN IN THE INSET ON TMP-3.
- STEP 5: USING RSD 1101.02 SHEET 1 OF 19 AND 1101.04 SHEET 1 OF 2 AS NECESSARY, COMPLETE ALL CONSTRUCTION INCLUDING THE FINAL LAYER OF SURFACE COURSE. INSTALL FINAL PAVEMENT MARKINGS ACCORDING TO THE PAVEMENT MARKING PLANS.
- STEP 6: REMOVE ALL WORK ZONE TRAFFIC CONTROL DEVICES.

9/4/2024
X:\2016\TR16.008.00 W-5601\W-5601EX\TMP\W5601EX TMP-1C.dgn
jbauman

TRANSYSTEMS
1 Glenwood Avenue
Raleigh, NC 27603
Tel: 919.789.9977
Fax: 919.789.9591
License: F-0453

APPROVED:  DATE: _____ SEAL			<h1 style="font-size: 2em;">PHASING</h1>
DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED			