OVERLAP PROGRAMMING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

Overlap	1	2	3
Туре	FYA 4 - Section	FYA 4 - Section	FYA 4 - Section
Included Phases	2	4	6
Modifier Phases	1	3	5
Trail Green	0	0	0
Trail Yellow	0.0	0.0	0.0
Trail Red	0.0	0.0	0.0

OUTPUT CHANNEL CONFIGURATION

Front Panel

Main Menu >Controller >More>Channels>Channels Config


Web Interface

Home >Controller >Advanced IO>Channels>Channel Configuration

Channel Configuration

Channel	Control Type	Control Source	Flash Yellow	Flash Red	Flash Alt	MMU Channel
1	Phase Vehicle	1		Х	Х	1
2	Phase Vehicle	2		Х		2
3	Phase Vehicle	3		Х	Х	3
4	Phase Vehicle	4		Х		4
5	Phase Vehicle	5		Х		5
6	Phase Vehicle	6		Х	Х	6
7	Phase Vehicle	7		Х		7
8	Phase Vehicle	8		Х	Х	8
9	Overlap	1		Х	Х	9
10	Overlap	2		Х	Х	10
11	Overlap	3		Х		11
12	Overlap	4		Х		12
13	Phase Ped	2				13
14	Phase Ped	4				14
15	Phase Ped	6				15
16	Phase Ped	8				16
17	Overlap	5		Х	Х	17
18	Overlap	6		Х		18

Notice Flash Red



MAXTIME STARTUR PROGRA
Front Panel Main Menu >Controlle
Web Interface Home >Controller >Ur
Modify parameters as
Start Up Parameters StartUp Clearance Hold 6
COUNTDOWN PEDES
Countdown Ped Signals are Ped Clearance Interval. Con for instructions on selecting th
FLASHER CIRCUI
IN ORDER TO INSURE THAT SIG SAME APPROACH, MAKE THE F

1. ON REAR OF PDA - REMOVE

2. ON REAR OF PDA - REMOVE

3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TH





		PROJECT REFERENCE NO.	SHEET NO.
TARTUP AND SOFTWARE FLASH ROGRAMMING DETAIL	l	U-3422A	Sig-6.2
>Controller >Unit			
ce troller >Unit			
meters as shown below and save changes.			
rameters Unit Flash Parameters rance Hold All Red Flash Exit Time 6			
Signals are required to display timing only during terval. Consult Ped Signal Module user's manual selecting this feature.			
CIRCUIT MODIFICATION DETAIL			
E THAT SIGNALS FLASH CONCURRENTLY ON THE AKE THE FOLLOWING FLASHER CIRCUIT CHANGE			
OVE WIRE FROM TERM. T2-4 AND TERMINATE ON OVE WIRE FROM TERM. T2-5 AND TERMINATE ON 2.			
OVE TIES ALL PHASES AND OVERLAPS TO FLASHE	R UNIT 1.		
		CAL DETAIL IS FOR	
	DESIGNED: Jul SEALED: REVISED: N/A		
Electrical Detail - Sheet 2 of 2	SEALED:		

SIG. INVENTORY NO. 06-1327