
ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL


(program controller as shown)

- 1. From Main Menu select 2. CONTROLLER
- 2. From CONTROLLER Submenu select | 2. VEHICLE OVERLAPS
- 3. Toggle once to position on Overlap B

OVERLAP B

Select TMG VEH OVLP [B] and 'PPLT FYA'





FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO ENSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- 1. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- 2. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

ECONOLITE ASC/3-2070 VEHICLE DETECTOR SETUP PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 3A & 7A


(program controller as shown) IMPORTANT

Program detectors per the input file connection and programming chart shown on sheet 1 before proceeding.


- 1. From Main Menu select 8. UTILITIES
- 2. From UTILITIES Submenu select | 1. COPY/CLEAR
- 3. Copy from DETECTOR PLAN "1" to DETECTOR PLAN "2".

COPY / CLEAR UTILITY FROM PHASE TIMING.... > PHASE TIMING.... TIMING PLAN.... > TIMING PLAN.... . PH DET OPT PLAN. . > PH DET OPT PLAN. . DETECTOR PLAN... 1 > DETECTOR PLAN... 2 TOGGLE TO SELECT A "FROM" AND A "TO" THEN PRESS ENTER

- 4. From Main Menu select 6. DETECTORS
- 5. From DETECTOR Submenu select | 2. VEHICLE DETECTOR SETUP
- 6. Place cursor in VEH DET PLAN [] position and enter "2".
 - Place cursor in VEH DETECTOR [] position and enter "3".
- Set delay time to "0".



- Place cursor in VEH DETECTOR [] position and enter "28". - Set assigned phase to "0".



- Place cursor in VEH DETECTOR [] position and enter "7". - Set delay time to "3".

> VEH DETECTOR [7] VEH DET PLAN [2] TYPE: N-NTCIP TS2 DETECTOR..... ECPI LOG..... NO DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 CALL OPTION.... YES DELAY TIME... 3.0 ← EXT OPTION. PASSAGE EXTENSION TIME. 0.0 USE ADDED INITIAL . CROSS SWITCH PH.. O LOCK IN..... NONE NTCIP VOL . OR OCC . PMT QUEUE DELAY- NO

- Place cursor in VEH DETECTOR [] position and enter "24". - Set assigned phase to "0".

VEH DETECTOR [24] VEH DET PLAN [2] TYPE: N-NTCIP TS2 DETECTOR..... ECPI LOG..... NO DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 ENSURE PHASE IS SET TO "O" CALL OPTION.... YES DELAY TIME... 3.0 EXT OPTION. PASSAGE EXTENSION TIME. 0.0 USE ADDED INITIAL . CROSS SWITCH PH., O LOCK IN..... NONE NTCIP VOL . OR OCC . PMT QUEUE DELAY- NO

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: Ø7-1438T2 DESIGNED: August 2024 SEALED: August 22, 2024 REVISED:

Signal Upgrade - Temporary Design 2 (TMP Phase III) - Electrical Detail - Sheet 2 of 3

ELECTRICAL AND PROGRAMMING

Prepared for the Offices of:

NC 68 (Eastchester Dr.)

SR 1556 (Gallimore Dairy Rd.) Guilford County

PLAN DATE: August 2024 REVIEWED BY: DT Sears PREPARED BY: WP Erickson-Jones REVIEWED BY:

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED 056142

Porter Jones 8/22/2024 SIG. INVENTORY NO. 07-1438T2

RKK 8601 Six Forks Road Suite 700 | Raleigh, North Carolina 27615-296 NC License No. F-0112 Engineers | Construction Managers | Planners | Scientists

Responsive People | Creative Solutions