

PHASING

PHASE I

STEP 1: USING ROADWAY STANDARD DRAWING (RSD) 1101.01 SHEET 3 OF 3, PLACE ADVANCE WARNING SIGNS ON SR 1620(FLETCHER MARTIN RD.) AND NC 251.

STEP 2: USING ROADWAY STANDARD DRAWING (RSD) 1101.02 SHEET 1 OF 19 AND RSD 1101.04 SHEET 1 OF 2, PLACE TRAFFIC CONTROL DEVICES AND CONSTRUCT NECESSARY BRIDGE AND ROADWAY WORK (UP TO, BUT NOT INCLUDING THE FINAL LAYER OF SURFACE COURSE) UNDER FLAGGERS, PLACE ANY TEMPORARY PAVEMENT MARKINGS AS NEEDED AND PRIOR TO THE FINAL LAYER.




STEP 3: USING ROADWAY STANDARD DRAWING (RSD) 1101.02 SHEET 1, OF 19, PLACE THE FINAL LAYER OF SURFACE COURSE AND FINAL PAVEMENT MARKINGS AS SHOWN ON THE PAVEMENT MARKING PLANS.

STEP 4: REMOVE ALL TRAFFIC CONTROL DEVICES AND OPEN SR 1620 (FLETCHER MARTIN RD.) TO TRAFFIC.

2/10/2025
G:\Projects_2024\RA302\302240126\Bridge\Traffic Control\TMP-3.dgn
jbauman

TRANSYSTEMS

1 Glenwood Avenue
Raleigh, NC 27603
Tel:919.789.9977
Fax:919.789.9591
License: F-0453

<div>APPROVED:  DATE: 8/18/2025 SEAL  DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED</div>		PHASING
---	---	---------