PROJ. REFERENCE NO.	SHEET NO.
W-5710X	TMP-3

PHASING

PHASE I

STEP 1: USING ROADWAY STANDARD DRAWING (RSD) 1101.01 SHEET 3 OF 3 PLACE ADVANCE WARNING SIGNS ON SR 2025, SR 2108, SR 2040, SR 2041, SR 2042.

NOTE: LOCAL ACCESS TO ALL RESIDENCES AND BUSINESSES WILL BE MAINTAINED DURING CONSTRUCTION.

NOTE: CONTRACTOR TO MAINTAIN CLOSURE OF ALL PROPOSED PEDESTRIAN FACILITIES AS THEY ARE CONSTRUCTED. USE ADA SIGNS/DEVICES

STEP 2: USING RSD 1101.02 SHEET 1 OF 19 AND RSD 1101.04 SHEET 1 OF 2, PLACE TRAFFIC CONTROL DEVICES AND BEGIN CONSTRUCTION AWAY FROM TRAFFIC, USING WEDGING TO MAINTAIN DRAINAGE AS NEEDED, AS SHOWN ON TMP-4 AND TMP-5 UP TO BUT NOT INCLUDING THE FINAL LAYER OF SURFACE COURSE.

COMPLETE THE WORK REQUIRED IN PHASE I, STEPS 3 & 4 WITHIN FORTY-TWO (42) CONSECUTIVE CALENDAR DAYS. THE CONTRACTOR SHALL NOT CLOSE SR 2025 (MIRANDA ROAD) FROM SEPTEMBER 15TH (OF ANY YEAR) TO MAY 15TH (OF THE FOLLOWING YEAR). SEE INTERMEDIATE CONTRACT TIMES.

STEP 3: USING RSD 1101.03 SHEET 1 AND 2 OF 9, CLOSE MIRANDA ROAD AND DETOUR TRAFFIC AS SHOWN ON TMP-8 AND TMP-9. THE OFF-SITE DETOUR IS TO BE INSTALLED BY THE CONTRACTOR. BEGIN -Y1- CONSTRUCTION UP TO BUT NOT INCLUDING THE FINAL LAYER OF SURFACE COURSE. SEE INSET ON TMP-4. -Y1- CLOSURE WORK TO CONTINUE AND COMPLETE IN STEP 4.

COMPLETE THE WORK REQUIRED IN PHASE I, STEP 4 WITHIN THREE (3)
CONSECUTIVE WEEKENDS OF THE CONTRACTOR'S CHOOSING, BEGINNING 8:00 P.M. ON
A FRIDAY, AND ENDING 6:00 A.M. THE FOLLOWING MONDAY FOR EACH WEEKEND. SEE
INTERMEDIATE CONTRACT TIMES.


STEP 4: USING RSD 1101.03 SHEET 1 OF 9, CLOSE OAKDALE AND SUNSET ROAD AND DETOUR TRAFFIC AS SHOWN ON TMP-10 AND TMP-11. THE OFF-SITE DETOUR IS TO BE INSTALLED BY THE CONTRACTOR. COMPLETE -Y1-CONSTRUCTION AND COMPLETE -L1-FROM STA. 15+00 TO STA. 18+00, -Y3-FROM STA. 10+50 TO STA. 10+75, AND -L2-FROM STA. 12+50 TO STA. 14+50, UP TO BUT NOT INCLUDING THE FINAL LAYER OF SURFACE COURSE.

PLACE TRAFFIC CONTROL DEVICES, TEMPORARY MARKINGS, AND PROPOSED SIGNING ACCORDING TO THE SIGNING PLANS AS SHOWN ON TMP-6 AND TMP-7, THEN USE WEDGING TO CREATE A TIE-IN TO THE PHASE II PATTERN AND SHIFT TRAFFIC INTO THE FINAL PATTERN.

PHASE II

STEP 1: USING RSD 1101.02 SHEET 1 AND 18 OF 19 AND RSD 1101.04 SHEET 1 OF 2, COMPLETE CONSTRUCTION AS SHOWN ON TMP-6 AND TMP-7, INCLUDING THE FINAL LAYER OF SURFACE COURSE, AND PLACE FINAL PAVEMENT MARKINGS ACCORDING TO THE PAVEMENT MARKING PLANS.

STEP 2: REMOVE ALL WORK ZONE TRAFFIC CONTROL DEVICES.



DOCUMENT NOT CONSIDERED FINAL

UNLESS ALL SIGNATURES COMPLETED

PHASING